

Function	Command	Answer	NOTE
Power ON	DM-4-1600.sys on	R DM-4-1600.sys on	
Power OFF	DM-4-1600.sys off	R DM-4-1600.sys off	
All Device State	T GETALL	R GETALL	R GETMODEL KCS DM-4-1600 R GETFIRM F3.5 R DM-4-1600.sys off ...
Monitoring	T STATUSGET	R STATUSGET 1 1 1 1 2 3 5	1°- 4° values indicate the states of the channels: <ul style="list-style-type: none"> • 0: No Load • 1: OK • 2: Overload • 3: Fault • 4: Low Input Signal 5° value indicates the level of temperature (1-4). 6° value indicates the temperature in Celsius grads.

TCP Command Delimitation

Commands sent to the device may require an end-of-line (EOL) character depending on the cinema server being used. The device itself does not enforce any specific command termination; the sending system must append the appropriate delimiter according to the server protocol requirements.

Server	Recommended Termination
Dolby IMS3000	LF (\n) or CR (\r)
Barco Alchemy ICMP-X	LF (\0A) or CR (\0D)

Refer to the documentation of the corresponding server to determine the required command termination format.