



# SPEAKER SETTINGS

		Fill in blank areas					
<b>Contact person and phone #</b>		<b>Jordi Casas</b>	#	+34 93 300 43 61			
<b>e-mail</b>		sk@kelonik.com					
1	<b>MAKE</b>	<b>KCS</b>					
2	<b>Model</b>	<b>S-7601</b>					
2a	Type (screen, surround, or sub)	SCREEN					
2b	full range, 2-way, 3-way, or dual low	3-WAY					
<b>LOW FREQUENCIES</b>							
3a	Nominal Impedance	4 ohms					
3b	HPF	Butt 24 dB/oct 35 Hz					
3c	LPF	LR 24 dB/oct 380 Hz					
3d	Gain (dB)	4 dB					
3e	Polarity						
3f	Delay (mS)						
3g	<b>Output EQ</b>	<b>EQ1</b>	<b>EQ2</b>	<b>EQ3</b>	<b>EQ4</b>	<b>EQ5</b>	<b>EQ6</b>
	Freq (Hz)	50 Hz					
	Q	3					
	Gain (dB)	+ 4,0 dB					
	Type	Parametric					
<b>MEDIUM HIGH FREQUENCIES</b>							
4a	Nominal Impedance	8 ohms					
4b	HPF	LR 24 dB/oct 380 Hz					
4c	LPF						
4d	Gain (dB)	0 dB					
4e	Polarity						
4f	Delay (mS)						
4g	<b>Output EQ</b>	<b>EQ1</b>	<b>EQ2</b>	<b>EQ3</b>	<b>EQ4</b>	<b>EQ5</b>	<b>EQ6</b>
	Freq (Hz)	4 kHz					
	Q	2					
	Gain (dB)	+ 4,0 dB					
	Type	Parametric					